



TOILET FOAM GASKETS



DIMENSIONS:

Foam Gasket Thickness	inches	1/2	3/4	1
Inner Diameter	mm	86	86	78
Outer Diameter	mm	135	135	135

INSTALLATION:

1. Place the foam gasket over the horn of the toilet (discharge outlet).
2. Place the toilet back over the bolts.
3. Carefully tighten nuts on bolts alternating from one side to the other.
4. Flush toilet to check if the seal has been made or not.

CAUTION:

Do not over tighten bolts as toilet may break