TOILET FOAM GASKETS



DIMENSIONS:

Foam Gasket Thickness	inches	1/2	3/4	1
Inner Diameter	mm	86	86	78
Outer Diameter	mm	135	135	135

INSTALLATION:

- 1. Place the foam gasket over the horn of the toilet (discharge outlet).
- 2. Place the toilet back over the bolts.
- 3. Carefully tighten nuts on bolts alternating from one side to the other.
- 4. Flush toilet to check if the seal has been made or not.

CAUTION:

Do not over tighten bolts as toilet may break